


FIG.4 PISTON - CRANKSHAFT



RL250

FIG.4 PISTON - CRANKSHAFT

Ref.No.	Part No.	Description	Q'ty		Remarks
			L	M	
1-1	12110-30000	PISTON	1	1	
1-2	12110-30710	PISTON	1	1	OS:0.5 } OPT
1-3	12110-30720	PISTON	1	1	
2-1	12140-30010	RING SET, piston	1	1	
2-2	12140-30710	RING SET, piston	1	1	OS:0.5 } OPT
2-3	12140-30720	RING SET, piston	1	1	
3	12151-15000	PIN, piston	1	1	
4	09381-18002	CIRCLIP	2	2	
5	09263-18005	BEARING	1	1	
6-1	12200-30830	CRANKSHAFT ASSY	1	-	to 12200-30002
6-2	12200-30002	CRANKSHAFT ASSY	-	1	
7-1	12161-30200	*ROD, connecting	1	-	to 12161-16400
7-2	12161-16400	*ROD, connecting	-	1	
8	12211-16400	*PIN, crank	1	1	
9	09263-25008	*BEARING	1	1	
10	09160-25004	*THRUST WASHER	2	2	25x42x1
11-1	12221-30000	*CRANKSHAFT, RH	1	-	to 12221-30001
11-2	12221-30001	*CRANKSHAFT, RH	-	1	
12-1	12261-30001	*CRANKSHAFT, LH	1	-	to 12261-30002
12-2	12261-30002	*CRANKSHAFT, LH	-	1	
13	08221-30426	SHIM	1	1	
14	09180-30012	SPACER	1	1	30x45x3

RL250

FIG.4 PISTON - CRANKSHAFT

Ref.No.	Part No.	Description	Q'ty		Remarks
			L	M	
15	08113-63050	BALL BEARING	1	1	
16	08113-63060	BALL BEARING	1	1	30x72x19
17	09283-35004	OIL SEAL	1	1	35x62x9
18	09283-30011	OIL SEAL	1	1	30x55x10
19-1	21111-38000	GEAR, primary drive	1	-	NT:18
19-2	21111-38001	GEAR, primary drive	1	1	NT:17
20	09140-18002	NUT	1	1	
21	09166-18001	WASHER	1	1	18x32x0.8
22	08341-31059	KEY	1	1	

RL250